



LOVATO ELECTRIC S.P.A.


24020 GORLE (BERGAMO) ITALIA
VIA DON E. MAZZA, 12
TEL. 035 4282111
TELEFAX (Nazionale): 035 4282200
TELEFAX (International): +39 035 4282400
E-mail info@LovatoElectric.com
Web www.LovatoElectric.com





- ① ISTRUZIONI DI MONTAGGIO PER OTTENERE CONTATTORI BFK
(Accessori G460-G464)
- ② ASSEMBLY INSTRUCTIONS TO OBTAIN BFK CONTACTORS
(Change kit G460-G464)
- ③ ANWEISUNG FÜR DIE UMSTELLUNG IM SCHÜTZ BFK
(Zubehör G460-G464)
- ④ INSTRUCCIONES DE MONTAJE PARA OBTENER
CONTACTORES BFK (accesorios G460, G464)



11 G460 + BF09A	=	BFK09
11 G460 + BF12A	=	BFK12
11 G460 + BF18A	=	BFK18
11 G460 + BF26A	=	BFK26

11 G460 + BF32A	=	BFK32
11 G464 + BF50	=	BF50K
11 G464 + BF65	=	BF65K
11 G464 + BF80	=	BF80K



5**6****8**

B	→	A
BFK09A	→	BF09A
BFK12A	→	BF12A
BFK18A	→	BF18A
BFK26A	→	BF26A
BFK32A	→	BF32A
BF50K	→	BF50
BF65K	→	BF65
BF80K	→	BF80

9