



LOVATO ELECTRIC S.P.A.

24020 GORLE (BERGAMO) ITALIA  
 VIA DON E. MAZZA, 12  
 TEL. 035 4282111  
 FAX (Nazionale): 035 4282200  
 FAX (International): +39 035 4282400  
 E-mail: info@LovatoElectric.com  
 Web: www.LovatoElectric.com



RF38...

I RELÈ TERMICO

D ÜBERSTROMRELAYS




E RELÈS TÉRMICOS

CN 热继电器


GB THERMAL OVERLOAD RELAY

F RELAIS DE PROTECTION MOTEUR


P RELÉ TÉRMICO








TEST




RESET



RFX38 04



Il riarmo automatico può essere pericoloso.  
 Automatic resetting can be dangerous.  
 Die automatische Rücksetzung kann gefährlich sein.  
 Réarmement automatique peut être dangereux.  
 El reinicio automático puede ser peligroso.  
 O rearramento automático pode ser peritoso.  
 自动的复位可能引发危险



		Phillips 2	Max 2x2.5mm <sup>2</sup> Max 2x14 AWG	Max 2x2.5mm <sup>2</sup> Max 2x14 AWG
		Ø 6mm		
		1...1.5Nm		
		Phillips 2	Max 2x10mm <sup>2</sup> Max 2x8 AWG	Max 2x6mm <sup>2</sup> Max 2x8 AWG
		Ø 6mm		
		2...2.5Nm		
RFX38 04		Phillips 2	Max 1x10mm <sup>2</sup> Max 1x8 AWG	Max 1x6mm <sup>2</sup> Max 1x8 AWG
		Ø 6mm		
		2...2.5Nm		

